

# **G & MAG Series**

**LCD Monitor** 

G273CQ (3CD0) MAG273CQR (3CD0)

User Guide

### **Contents**

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	6
Monitor Overview	8
Connecting the Monitor to PC	11
OSD Setup	13
Navi Key	13
Hot Key	14
OSD Menus	15
Gaming	16
Professional	18
Image	19
Input Source	20
PIP/PBP	21
Navi Key	22
Setting	23
Specifications	25
Preset Display Modes	27
Troubleshooting	29
Safety Instructions	30
TÜV Rheinland Certification	32
Regulatory Notices	33

#### Revision

V1.0, 2022/09

### **Getting Started**

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

### **Package Contents**

Monitor	G273CQ MAG273CQR		
Documentation	Quick Start Guide		
	Stand Base with Quick Release Fastener		
A	Screw(s) for Wall Mount Bracket(s)		
Accessories	Power Cord		
	External Power Supply (Optional)		
Cablas	HDMI Cable (Optional)		
Cables	DisplayPort Cable (Optional)		




# Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.


### **Installing the Monitor Stand**

- 1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the quick release fastener to secure the base.
- **4.** Make sure the stand assembly is properly installed before setting the monitor

#### G273CQ



#### MAG273CQR





- Remove the screws on the monitor groove if needed before installing the stand.
- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any mechanical damages to the product including removal of the polarizing film may affect the warranty!



### **Adjusting the Monitor**


This monitor is designed to maximize your viewing comfort with its adjustment capabilities.




# Important


- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor backwards before pivoting it.

#### G273CQ




### MAG273CQR






### **Monitor Overview**

### G273CQ



### MAG273CQR




	D
0	Power LED
	Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode.
2	Power Button & Navi Key
3	Kensington Lock
4	Power Jack
6	HDMI Port HDMI  NGINGSPHISH MATHEFACE
6	DisplayPort
7	Headphone Jack
8	USB Type-C Port
	This port supports DisplayPort Alternate (DP Alt) Mode and up to 5V/3A (15W) power delivery.
9	USB 2.0 Type-B Upstream Port
U	For USB Upstream Cable.
	To Monitor
	<b>Important</b>
	Check the package for USB Upstream Cable and connect it to the PC and monitor. Once this cable is connected, the USB Type-A To PC Downstream Ports on the monitor will be
	ready for use.
1	USB 2.0 Type-A Port


### Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Assemble the external power supply & power cord. (Figure A)
- **4.** Connect the external power supply to the monitor power jack. (Figure B)
- **5.** Plug the power cord into the electrical outlet. (Figure C)
- **6.** Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto detect the signal source.

#### **G273CQ**



### MAG273CQR



## **OSD Setup**

This chapter provides you with essential information on OSD Setup.




## / Important

All information is subject to change without prior notice.


### **Navi Key**

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.

#### G273CQ



#### MAG273CQR



#### Up/ Down/ Left/ Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus

#### Press (OK):


- launching the On-Screen Display (OSD)
- entering submenus
- confirming a selection or setting

### **Hot Key**


- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

### **OSD Menus**

#### **G273CQ**



#### MAG273CQR





When receiving HDR signals, Night Vision, MPRT, Low Blue Light, HDCR, Brightness, Contrast, Color Temperature, and PIP/PBP will be grayed out.

### **Gaming**

1st Level Menu	2nd/3rd Level Menu	Description	
Game Mode	User	Use Up or Down Button to select and	
	FPS	preview mode effects.     Press the OK Button to confirm and	
	Racing	apply your mode type.	
	RTS		
	RPG		
Night Vision	OFF	This function optimizes background	
	Normal	brightness and is recommended for FPS games.	
	Strong		
	Strongest		
	A.I.		
Response Time	Normal	Users can adjust Response Time in	
	Fast	any mode.  • Response Time will be grayed out	
	Fastest	while MPRT is enabled.	
MPRT	OFF	When MPRT is enabled, Brightness cannot be enabled and will be grayed out.	
	ON	HDCR and MPRT cannot be enabled simultaneously.	
		Response time will be grayed out while MPRT is enabled.	
		MPRT is available when the refresh rate is over 85Hz.	
		MPRT has to be disabled while Adaptive-Sync is set to ON.	

1st Level Menu	2nd/3rd L	evel Menu	Description
Refresh Rate	Location	Left Top	Location is adjustable in OSD Menu.
		Right Top	Press the OK Button to confirm and apply your Refresh Rate Location.
		Left Bottom	This monitor follows and works at the Operating System's preset Screen Refresh Rate.
		Right Bottom	Refresh Rate.
		Customize	
	OFF		
	ON		
Alarm Clock	Location	Left Top	After setting the time, press the OK
		Right Top	Button to activate the timer.  • Users have to manually restore their
		Left Bottom	preset Alarm Clock after any AC power loss and reconnection.
		Right Bottom	
		Customize	
	OFF		
	15:00	00:01 ~	
	30:00	99:59	
	45:00		
	60:00		
KVM	Auto		Auto allows the monitor to
(MAG273CQR)	Upstream		automatically switch between USB input sources, such as keyboards,
	Type-C		mice or other USB devices.
			Users can also designate Upstream port or USB Type-C as the only USB signal source.

1st Level Menu	2nd/3rd Level Menu	Description
Screen	None	Users can adjust Screen Assistance
Assistance	lcon	in any mode.
	+ Î + ( · ) + Î + ( · )	
	Position	
	Reset	
Adaptive-Sync	OFF	Adaptive-Sync prevents screen
	ON	tearing.     MPRT will be disabled if Adaptive- Sync is enabled.

### Professional

1st Level Menu	2nd Level Menu	Description
Pro Mode	User	Use Up or Down Button to select and
	Anti-Blue	<ul> <li>preview mode effects.</li> <li>Press the OK Button to confirm and apply</li> </ul>
	Movie	your mode type.
	Office	The default setting "Eco" mode meets the requirements of TÜV Rheinland's
	sRGB	"Low Blue Light" standard and Eyesafe certification.
	Eco	cer uncation.
Low Blue Light	OFF	Low Blue Light protects your eyes against
	ON	blue light. When enabled, Low Blue Light adjusts the screen color temperature to a more yellow glow.
		When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light.
		This monitor is a Low Blue Light monitor which will decrease the blue light emitted without adjusting the OSD settings.

1st Level Menu	2nd Level Menu	Description
HDCR	OFF	HDCR enhances image quality by increasing the contrast of images.
	ON	When HDCR is set to ON, Brightness will be grayed out.
		HDCR and MPRT cannot be enabled simultaneously.
MPRT	OFF	When MPRT is enabled, Brightness cannot be enabled and will be grayed out.
	ON	HDCR and MPRT cannot be enabled simultaneously.
		Response time will be grayed out while MPRT is enabled.
		MPRT is available when the refresh rate is over 85Hz.
		MPRT has to be disabled while Adaptive- Sync is set to ON.
Image	OFF	Image Enhancement enhances image
Enhancement	Weak	edges to improve their acutance.
	Medium	
	Strong	
	Strongest	

# Image

1st Level Menu	2nd/3rd Level Menu	Description
Brightness	0-100	<ul> <li>Properly adjust Brightness according to the surrounding lighting.</li> </ul>
		Brightness will be grayed out when MPRT or HDCR are enabled.
Contrast	0-100	Properly adjust Contrast to relax your eyes.
Sharpness	0-5	Sharpness improves clarity and details of images.

1st Level Menu	2nd/3rd Level Menu		Description
Color	Cool		Use Up or Down Button to select and preview mode effects.
Temperature	Normal		Press the OK Button to confirm
	Warm		and apply your mode type.
	Customization R (0-100) G (0-100)	Users can adjust Color     Temperature in Customization	
		mode.	
		B (0-100)	
Screen Size	2e Auto 4:3 16:9		Users can adjust Screen Size in
			any mode, any resolution and any screen refresh rate.
	1:1		

### **Input Source**

1st Level Menu	2nd Level Menu	Description	
HDMI1		Users can adjust Input Source in any mode.	
HDMI2			
DP			
Type-C (MAG273CQR)			
Auto Scan	OFF	Users can use the Navi Key to select Input	
	ON	Source at below status:  • While "Auto Scan" is set to "OFF" with the monitor at power saving mode;	
		While "No Signal" message box is shown on the monitor.	

### PIP/PBP

1st Level Menu	2nd/3rd Level Menu		Description
OFF			PIP (Picture in Picture) allows
PIP	Source	HDMI1	users to simultaneously display multiple video sources on
		HDMI2	one screen. One program is
		DP	displayed on the full screen at the same time as one or more
		Type-C (MAG273CQR)	other programs are displayed in inset windows.
	PIP Size	Small	PBP (Picture by Picture) is a
		Medium	similar feature that displays two
		Large	input sources side-by-side on the screen.
	Location	Left Top	Display Switch allows users to
		Right Top	switch between primary and
		Left Bottom	secondary input sources.
		Right Bottom	If there is only one signal input, the Display Switch and Audio
		Customize	Switch will be grayed out.
	Display Swit	ch	
	Audio Switch	ו	
PBP	Source 1	HDMI1	
		HDMI2	
		DP	
		Type-C (MAG273CQR)	
	Source 2	HDMI1	
		HDMI2	
		DP	
		Type-C (MAG273CQR)	
	Display Switch		
	Audio Switch	1	

## Navi Key

1st Level Menu	2nd Level Menu	Description
Up	OFF	All Navi Key items can be adjusted via
Down Left Right	Brightness	OSD Menus.
	Game Mode	
	Screen Assistance	
	Alarm Clock	
	Input Source	
	PIP/PBP Mode	
	Refresh Rate	
	Info. On Screen	
	Night Vision	
	KVM (MAG273CQR)	

### Setting

1st Level Menu	2nd Level Menu	Description			
Language	繁體中文	Users have to press the OK Button to			
	English	confirm and apply the Language setting.  • Language is an independent setting.			
	Français	Users' own language setting will override			
	Deutsch	the factory. When users set Reset to Yes, Language will not be changed.			
	Italiano				
	Español				
	한국어				
	日本語				
	Русский				
	Português				
	简体中文				
	Bahasa Indonesia				
	Türkçe				
	(More languages coming soon)				
Transparency	0~5	Users can adjust Transparency in any mode.			
OSD Time out	5~30s	Users can adjust OSD Time out in any mode.			
RGB LED	OFF	• Users can adjust RGB LED to ON or OFF.			
(MAG273CQR)	ON				
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.			
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.			
Info. On Screen	OFF	The information of the monitor status will			
	ON	be shown on the right side of the screen.			
DP	OFF	• To overclock the monitor refresh rate,			
OverClocking	ON	users have to set DP OverClocking to ON.			

1st Level Menu	2nd Level Menu	Description		
HDMI CEC	OFF ON	HDMI CEC (Consumer Electronics Control) supports Sony PlayStation®, Nintendo® Switch™, Xbox Series XIS consoles and		
		various audio-visual devices that are CEC-capable.		
		If HDMI CEC is set to ON:		
		The monitor will automatically power o when the CEC device is turned on.		
		The CEC device will enter power saving mode when the monitor is turned off.		
		<ul> <li>When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later.</li> </ul>		
Reset	YES	Users can Reset and restore settings to     signal OSP Default in any mode.		
	NO	original OSD Default in any mode.		

# **Specifications**

Model	G273CQ	MAG273CQR		
Size	27 inch			
Curvature	1500R			
Panel Type	VA			
Resolution	2560 x 1440			
Aspect Ratio	16:9			
Brightness (nits)	300 (typ.)			
Contrast Ratio	3000:1			
Refresh Rate	170Hz			
Response Time	1ms (MPRT) 4ms (GtG) 14ms (Tr + Tf)			
1/0	<ul> <li>DisplayPort x1</li> <li>HDMI Port x2</li> <li>Headphone Jack x1</li> </ul>	<ul> <li>USB Type-C Port x1</li> <li>DisplayPort x1</li> <li>HDMI Port x2</li> <li>Headphone Jack x1</li> <li>USB 2.0 Type-A Port x2</li> <li>USB 2.0 Type-B Upstream Port x1</li> </ul>		
View Angles	178°(H) , 178°(V)			
DCI-P3*/ sRGB	90% / 115%			
Surface Treatment	Anti-glare			
Display Colors	1.07B (8 bit + FRC)			
Monitor Power Options	19.0V === 2.58A	19.0V === 3.42A		
External Power Supply	Model: ADS-65HI-19A-1 19050E	Model: ADS-65HI-19A-1 19065E		
Power Input	100~240Vac, 50~60Hz, 1.5A max	100~240Vac, 50~60Hz, 1.5A max		
Power Output	19.0V === 2.58A	19.0V === 3.42A		

Model		G273CQ MAG273CQR			
Adjustment (Tilt)		-5° ~ 20°			
Adjustment (He	eight)		0-110mm		
Adjustment (Sv	vivel)		-20° ~ 20°		
Adjustment (Pivot)					
Kensington Lock		Yes			
VESA Mounting		<ul> <li>Plate Type: 75 x 75 mm</li> <li>Screw Type: M4 x 10 mm</li> <li>Thread Diameter: 4 mm</li> <li>Thread Pitch: 0.7 mm</li> <li>Thread Length: 10 mm</li> </ul>			
Dimension (W x D x H)		611.49 x 215.62 x 458.41 mm	611.49 x 213.95 x 538.71 mm		
Weight		4.55 Kg (net) 6.40Kg (gross)	5.70 Kg (net) 7.90 Kg (gross)		
Operating Environment		<ul> <li>Temperature: 0°C to 40°C</li> <li>Humidity: 20% to 90%, non-condensing</li> <li>Altitude: 0 ~ 5000m</li> </ul>			
	Storage	<ul><li>Temperature: -20°C to 60°C</li><li>Humidity: 10% to 90%, non-condensing</li></ul>			

<sup>\*</sup> Based on CIE1976 test standards.

# **Preset Display Modes**



All information is subject to change without prior notice.

	Resolution		G273CQ		MAG273CQR	
Standard			НДМІ	DP	HDMI	DP Type-C
VGA	640x480	@60Hz	V	V	٧	٧
		@67Hz	V	V	V	٧
		@72Hz	V	V	V	V
		@75Hz	V	V	V	V
Dos-Mode	720x480	@60Hz	V	V	V	٧
	720x576	@50Hz	V	V	٧	٧
SVGA	800x600	@56Hz	V	V	V	٧
		@60Hz	V	V	V	٧
		@72Hz	V	V	V	٧
		@75Hz	V	V	V	٧
XGA	1024x768	@60Hz	V	V	V	٧
		@70Hz	V	V	V	٧
		@75Hz	V	V	V	V
SXGA	1280x1024	@60Hz	V	V	V	V
		@75Hz	V	V	V	V
WXGA+	1440x900	@60Hz	V	V	V	V
WSXGA+	1680x1050	@60Hz	V	V	V	V
QHD	2560x1440	@60Hz	V	V	V	V
		@120Hz	V	V	V	V
		@144Hz	V	V	V	V
		@165Hz		V		V
		@170Hz		V*		V*
Video	720P		V	V	V	V
Timing Resolution	1080P @60Hz		V	V	V	V
	1080P @120Hz		V	V	V	V
	2160P @30Hz		V		V	
	2160P @60Hz		V		V	
PBP Mode	1280x1440 @60Hz		V	V	V	V

<sup>\*</sup> Users have to set DP OverClocking to ON. This is the highest refresh rate supported by DP OverClocking. If any monitor error occurs during overclocking, please downscale the refresh rate.

### **Troubleshooting**

#### The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

#### No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

#### The screen image is not properly sized or centered.

• Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

#### No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

#### The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- · Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

#### The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

### Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

#### Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

#### **Battery**

Please take special precautions if this device comes with a battery.

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
- Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting
  of a battery, which can result in an explosion.
- Avoid leaving a battery in an extremely high temperature or extremely low air pressure environment that can result in an explosion or the leakage of flammable liquid or gas.
- Do not ingest battery. If the coin/button cell battery is swallowed, it can cause severe internal burns and can lead to death. Keep new and used batteries away from children.

#### **European Union:**



Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.

#### BSMI:



#### 廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

#### California. USA:



The button cell battery may contain perchlorate material and requires special handling when recycled or disposed of in California. For further information please visit: https://dtsc.ca.gov/perchlorate/

#### **Environment**

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening: that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.
- If any of the following situations arises, get the device checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the device.
  - The device has been exposed to moisture.
  - The device does not work well or you can not get it working according to the User Guide.
  - The device has dropped and damaged.
  - The device has obvious sign of breakage.

### **TÜV Rheinland Certification**

### TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

#### TÜV Rheinland Flicker Free Certification

• TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.



- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

### Regulatory Notices

### **CE Conformity**

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

### FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

#### Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

#### MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA [626] 913-0828 www.msi.com

#### WFFF Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



#### Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

#### RoHS Statement

#### Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

#### India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

#### Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

#### Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

#### Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

#### Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

### **Environmental Policy**

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- · Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

### Warning!

Overuse of screens is likely to affect eyesight.

#### Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

### Copyright and Trademarks Notice

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.

### **Technical Support**

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.